

# Instruction Booklet

## CUBE (RX-202)

---

Please read all instructions  
carefully before opening box



1


PULL YOUR REXframe®  
FABRIC OUT OF THE BOX  
& UNWRAP YOUR  
EXTRUSION

CAREFUL NOT TO CUT  
INTO THE BAGS OR THE BOX  
AS YOU COULD DAMAGE  
THE FABRIC



2


INSERT THE RX-105 LENGTHS INTO THE RX-202 KNUCKLE  
AS SHOWN



# RX-202 Knuckle


3

CONTINUE TO INSERT THE HORIZONTAL RX-105 LENGTHS. LOCK THEM INTO PLACE BY INSERTING THE SUPPLIED SCREWS AND TIGHTENING WITH AN ALLEN KEY




4

ONCE THE RX-105 LENGTHS ARE IN PLACE, INSERT THE UPRIGHT RX-107 POSTS





5

INSERT SCREWS AND  
TIGHTEN WITH AN  
ALLEN KEY



8

INSERT THE FABRIC INTO THE EXTRUSION STARTING WITH THE CORNERS ENSURE THE SILICON GASKET IS CONCEALED




9

FOLLOW THE DIAGRAM BELOW FOR THE REMAINING SILICON GASKET EDGE.


STARTING WITH ALL CORNERS

ENSURE SILICON GASKET EDGE ON FABRIC IS PUSHED AS FAR INTO THE CHANNEL AS POSSIBLE, THIS SHOULD SUBSIDE ANY WRINKLES THAT MAY HAVE APPEARED.



# Inserting Fabric

10



CONTINUE WITH THE MIDDLE OF EACH LENGTH,  
AND THEN THE REMAINDER OF THE FABRIC

11



CONTINUE UNTIL ALL THE FABRIC HAS BEEN FULLY INSERTED