

Instruction Booklet

CUBE (RX-200 & RX-202)

Please read all instructions
carefully before opening box



1


PULL YOUR REXframe®
FABRIC OUT OF THE BOX
& UNWRAP YOUR
EXTRUSION

CAREFUL NOT TO CUT
INTO THE BAGS OR THE BOX
AS YOU COULD DAMAGE
THE FABRIC




2

INSERT THE RX-107 INTO
THE RX-200 KNUCKLE.



3


INSERT AND TIGHTEN THE SCREW WITH
THE SUPPLIED ALLEN KEY



RX-200 Knuckle


4

CONTINUE TO INSERT
THE RX-107 LENGTHS
INTO THE CORNER AND
TIGHTEN THE SCREWS




5

INSERT THE VERTICAL
RX-107 POSTS





6

INSERT SCREWS AND
TIGHTEN WITH AN
ALLEN KEY



7

INSERT THE RX-105 LENGTHS INTO THE RX-202 KNUCKLE
AS SHOWN




8

CONTINUE TO INSERT THE HORIZONTAL RX-105 LENGTHS.
LOCK THEM INTO PLACE BY INSERTING THE SUPPLIED SCREWS
AND TIGHTENING WITH AN ALLEN KEY

RX-202 Knuckle


9

ONCE THE RX-105
LENGTHS ARE IN
PLACE, INSERT THE
UPRIGHT RX-107 POSTS





10

INSERT SCREWS AND
TIGHTEN WITH AN
ALLEN KEY



11

INSERT THE FABRIC INTO THE EXTRUSION STARTING WITH THE CORNERS ENSURE THE SILICON GASKET IS CONCEALED



12

FOLLOW THE DIAGRAM BELOW FOR THE REMAINING SILICON GASKET EDGE.


STARTING WITH ALL CORNERS

ENSURE SILICON GASKET EDGE ON FABRIC IS PUSHED AS FAR INTO THE CHANNEL AS POSSIBLE, THIS SHOULD SUBSIDE ANY WRINKLES THAT MAY HAVE APPEARED.



Inserting Fabric

13



CONTINUE WITH THE MIDDLE OF EACH LENGTH,
AND THEN THE REMAINDER OF THE FABRIC

14



CONTINUE UNTIL ALL THE FABRIC HAS BEEN FULLY INSERTED