

Instruction Booklet

CUBE (RX-202)
with RX-111

Please read all instructions
carefully before opening box



1


PULL YOUR REXframe®
FABRIC OUT OF THE BOX
& UNWRAP YOUR
EXTRUSION

CAREFUL NOT TO CUT
INTO THE BAGS OR THE BOX
AS YOU COULD DAMAGE
THE FABRIC



2


INSERT THE RX-105 LENGTHS INTO THE RX-202 KNUCKLE
AS SHOWN



RX-202 Knuckle


3

CONTINUE TO INSERT THE HORIZONTAL RX-105 LENGTHS. LOCK THEM INTO PLACE BY INSERTING THE SUPPLIED SCREWS AND TIGHTENING WITH AN ALLEN KEY




4

ONCE THE RX-105 LENGTHS ARE IN PLACE, INSERT THE UPRIGHT RX-107 POSTS




5

INSERT SCREWS AND
TIGHTEN WITH AN
ALLEN KEY




6

INSERT THE HEAVY DUTY STRAIGHT JOINERS, ENSURING THE HOLES ARE CORRECTLY ALIGNED




7

INSERT SCREWS THEN TIGHTEN USING THE ALLEN KEY




8

INSERT THE CORRESPONDING LENGTH ENSURING THE HOLES ARE CORRECTLY ALIGNED




9

INSERT AND TIGHTEN
THE SCREWS USING
THE ALLEN KEY




10

INSERT THE SUPPORT
ENSURING IT ALIGNS AT THE
CENTRE OF THE JOIN





11

TIGHTEN THE SCREWS
USING THE SUPPLIED
LOCK KEY



12

INSERT THE FABRIC INTO THE EXTRUSION STARTING WITH THE CORNERS ENSURE THE SILICON GASKET IS CONCEALED




13

FOLLOW THE DIAGRAM BELOW FOR THE REMAINING SILICON GASKET EDGE.


STARTING WITH ALL CORNERS

ENSURE SILICON GASKET EDGE ON FABRIC IS PUSHED AS FAR INTO THE CHANNEL AS POSSIBLE, THIS SHOULD SUBSIDE ANY WRINKLES THAT MAY HAVE APPEARED.



Inserting Fabric

14



CONTINUE WITH THE MIDDLE OF EACH LENGTH,
AND THEN THE REMAINDER OF THE FABRIC

15



CONTINUE UNTIL ALL THE FABRIC HAS BEEN FULLY INSERTED